# CABINET PARTS

For Model: 3XART721F00
(Black)

REFRIGERATOR



| | | |
|---|---|---|
| 1 | | Cabinet (Not A Serviceable Part) |
| 2 | 2174748 | Front Roller (2) |
| 3 | 489456 | Screw |
| 4 | 981122 | Roller (Rear) (2) |
| 5 | 489427 | Screw |
| 6 | 2155013 | Clip, Grille |
| 7 | 489478 | Screw |
| 9 | 2181911 | Shim |
| 10 | 2158579 | Encloser, Terminal Block |
| 11 | 1129346 | Terminal Block |
| 12 | 1129449 | Bushing |
| 13 | 2196048 | Shim, Hinge Top |
| 14 | 489284 | Screw |
| 15 | 2151694 | Hinge Cover |
| 16 | 2171851 | Hinge Bottom (2) |
| 17 | 489211 | Screw |
| 18 | 489399 | Screw |
| 21 | 1127272 | Filler, Wrapper |
| 22 | 2155476 | Grille |
| 23 | 489367 | Screw |
| 24 | 2165297 | Wiring Assembly |
| 25 | 2167227 | Gasket |
| 26 | 489463 | Screw |
| 27 | 2196046 | Hinge, Top (2) |
| 40 | 1129332 | Service Cord |
| 41 | 940139 | Drain Fitting |
| 42 | 1108438 | Extension Tube |
| 43 | 1108439 | Clip, Drain Tube |
| 47 | 2189567 | Cover, Unit |
| 49 | 2155938 | Hinge Cover |
| 52 | 489348 | Clamp |
| 53 | 489084 | Screw |
| 54 | 2155311 | Door Closer, Lower Cam (2) |
| 55 | 489483 | Screw |

# REFRIGERATOR LINER PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | | Liner (Not A Serviceable Part) |
| 2 | 2194744 | Escutcheon, Meat Pan Control |
| 3 | 2182757 | Slide, Meat Pan Control |
| 4 | 2155290 | Reservoir |
| 5 | 2171846 | Release Valve |
| 6 | 2181796 | Shelf Ladder (2) |
| 7 | 487539 | Screw (6) |
| 8 | 1110718 | Stud (8) |
| 9 | 2172943 | Stud, Left Front |
| 10 | 2174150 | Glass, Cover |
| 11 | 489290 | Screw (2) |
| 13 | 2194982 | Shelf, Glass (3) |
| 14 | 2179259 | Glass, Cover |
| 15 | 2194578 | Crisper Cover |
| 16 | 2179350 | Deflector |
| 17 | 2194905 | Trim, Crisper Pan |
| 18 | 2189601 | Meat Pan Cover |
| 19 | 2194904 | Crisper Pan |
| 20 | 2194907 | Meat Pan |
| 21 | 2169933 | Egg Bin |
| 22 | 1123919 | Bracket Retainer |
| 23 | 489478 | Screw |
| 24 | 2175155 | Air Diffuser Assembly |
| 25 | 2161470 | Air Diffuser Cover |
| 26 | 2150330 | Cover, Conduit |
| 27 | 486298 | Screw |
| 29 | 2182147 | Louver |
| 30 | 842534 | Clip, Air Duct |
| 31 | 488280 | Screw |
| 32 | 2179404 | Rcak, Wine & Egg |
| 33 | 2194906 | Trim, Meat Pan |
| 34 | 2179561 | Extension |
| 35 | 2164373 | Egg Carrier |

# FREEZER LINER PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | | Liner (Not A Seviceable Part) |
| 2 | 1115380 | Slide, Ice Door |
| 3 | 2171712 | Door, Ice Compartment |
| 5 | 489478 | Screw |
| 6 | 842534 | Clip, Air Duct (2) |
| 7 | 1115317 | Support, Stud (4) |
| 8 | 2174269 | Shelf (1) |
| | 2174270 | Shelf (2) |
| 11 | 2171707 | Freezer Bin |
| 13 | 2176134 | Grommet (4) |
| 14 | 2155572 | Wiring Cover |
| 15 | 489355 | Screw |
| 19 | 1115373 | Switch, Rocker Arm |
| 20 | 946355 | Stud |
| 21 | 946356 | Stud, R.S.Front |
| 22 | 1106982 | Stud, L.S. Rear |
| 28 | | Slide, Ice Container |
| | 1115383 | Left Side |
| | 1119293 | Right Side |
| 29 | 489100 | Screw |

# MOTOR AND ICE CONTAINER PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 2183728 | Bracket, Motor |
| 2 | 2165167 | Motor, Dispenser |
| 3 | 2165210 | Soleniod Assembly |
| 4 | 2149100 | Guide, Solenoid |
| 5 | 2169193 | Shroud, Light |
| 7 | 2169490 | Wiring Assembly, Ice Dispenser |
| 8 | 489399 | Screw |
| 9 | 983663 | Coupling, Motor |
| 10 | 489478 | Screw |
| 11 | 2162085 | Socket, Light |
| 13 | | Slide, Container |
| | 1119293 | Right Side |
| | 1119237 | Left Side |
| 14 | 2196090 | Ice Container |
| 15 | 983668 | Coupling, Conveyor |
| 16 | 1118480 | Stop, Cone |
| 17 | 1119074 | Feeder Cone |
| 18 | 1119005 | Spacer, Step (3) |
| 19 | 1119007 | Spacer, Flat (2) |
| 20 | 1119006 | Blade, Rotary |
| 21 | 1119012 | Blade, Rotary |
| 22 | 1119013 | Blade, Rotary |
| 23 | 489235 | Washer, Plain |
| 24 | 1119009 | Blade, Fixed (2) |
| 25 | 2157405 | Block, Blade |
| 26 | 489229 | Roll Pin |
| 27 | 2181957 | Conveyor |
| 28 | 2171681 | Drum |
| 29 | 1118470 | Drive Bar |
| 30 | 2171682 | Floating Baffle |
| 31 | 1119018 | Nut, Bearing |
| 32 | 2169938 | Control Arm |
| 33 | 1119020 | Spring, Return |
| 34 | 1119021 | Retainer Clip, Rod |
| 35 | 488886 | Screw |
| 36 | 1129563 | Shield, Wiring |
| 37 | 2180348 | Housing, Crusher |
| 38 | 1119017 | Deflector, Ice |
| 39 | 489234 | Washer, Plain |
| 40 | 489236 | Retainer Ring |
| 41 | 2152021 | Sleeve |
| 44 | 2171709 | Front Cover, Ice Container |
| 45 | 851682 | Light Bulb |
| 46 | 2171706 | Light Lens, Dispenser |

# REFRIGERATOR DOOR PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 2194995B | Refrigerator Door Panel (Also Order Item 20) |
| 2 | 2155335 | Tap Plate |
| 3 | 2182132 | Door Closer, Upper Cam |
| 4 | 489420 | Screw |
| 5 | 2195952 | Bracket, Door Stop |
| 7 | 2194778B | Endcap, Handle |
| 8 | 2194776B | Retainer, Insert |
| 9 | 3400852 | Screw |
| 10 | 1117766 | Gasket Retainer, Side (2) |
| 11 | 1118301 | Gasket Retainer, Top & Bottom |
| 12 | 2156852 | Door Gasket, Magnetic |
| 13 | 509929 | Cap, Hinge Sleeve |
| 14 | 2173832 | Insert, Handle |
| 15 | 1119055 | Door Dike, Handle Side |
| 16 | 489463 | Screw |
| 17 | 941242 | Screw, Anchor |
| 18 | 3400012 | Screw |
| 20 | 876029 | Foam Insulation (Required When Replacing Exterior Door Panel) |
| 21 | 1116986 | Pin Plate |
| 22 | 1118048 | Pin Plate |
| 23 | 1115379 | Door Dike, Hinge Side |
| 24 | 2177882 | Door Bin, Deep (2) |
| 27 | 1129278 | Interior Door Panel (Also Order Item #15) |
| 28 | 2177883 | Door Bin (2) |
| 29 | 2148289 | Compartment Door |
| 30 | 2188148 | Trim, Door Compartment |
| 31 | 489101 | Screw (30) |

# FREEZER DOOR PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 2194998B | Freezer Door Panel (Also Order Item 11) |
| 2 | 2198369 | Clip |
| 3 | 2194776B | Retainer, Insert |
| 4 | 939886 | Cap, Hinge Sleeve |
| 5 | 2194778B | End Cap (2) |
| 8 | 1117767 | Retainer, Gasket |
| 9 | 489463 | Screw |
| 10 | 2156853 | Door, Gasket Magnetic |
| 11 | 876029 | Foam Insulation (Required When Replacing Exterior Door Panel) |
| 12 | 939101 | Screw Anchor (3) |
| 13 | 1126179 | Panel, Interior Door |
| 14 | 2189738 | Trim, Door Shelf (4) |
| 15 | 489101 | Screw |
| 16 | 2147080 | Tube, Water Line |
| 17 | 2198271 | Harness, Door |
| 18 | 2177884 | Trim, Door Shelf |
| 19 | 489000 | Screw |
| 20 | 2198196 | Tube, Door Wiring |
| 21 | 3400012 | Screw |
| 22 | 2149014 | Insulation, Dispenser |
| 23 | 2180204 | Chute, Ice |
| 24 | 2155335 | Tap Plate |
| 25 | 2182132 | Door Closer, Upper Cam |
| 26 | 2162412 | Housing Connector |
| 27 | 489420 | Screw |
| 28 | 2195952 | Bracket, Door Stop |
| 29 | 2173832 | Insert, Handle |
| 30 | 3400852 | Screw |
| 32 | 1117766 | Retainer, Gasket |

# DISPENSER FRONT PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 2180210 | Pin |
| 2 | 2180209 | Spring, Torsion |
| 3 | 2194719 | Retainer, Levers |
| 4 | | Housing, Dispenser (Not A Servicable Item) |
| 5 | 489101 | Screw |
| 6 | 625834 | Spacer, Switch (2) |
| 7 | 2195051 | Strain Relief |
| 8 | 2180236 | Switch Assembly (Also Order Item # 39) |
| 9 | 2180351 | Door, Ice |
| 10 | 2180208 | Door Mechanism Assembly |
| 11 | 2187011 | Dispeser Heater |
| 12 | 2180223 | Mechanism Delay |
| 13 | 2180325 | Grille, Overflow |
| 14 | 2180240 | Wire Assembly |
| 22 | 2180225 | Water Fitting Assembly (Includes Water Tube) |
| 24 | 2195089B | Lever Assembly, Ice Dispenser |
| 25 | 2180224 | Guide, Ice |
| 29 | 2180200 | Lamp Holder |
| 30 | 2162361 | Switch (4) |
| 33 | 2183771 | Bracket, Control |
| 34 | 989331 | Bulb, Light |
| 38 | 2195090B | Lever Assembly, Water Dispenser |
| 39 | 2187029B | Overlay, Front Cover |
| 40 | 2197745B | Front Cover Assembly (Includes Items 8, 14 & 39) |
| 45 | 489000 | Screw |

# AIR FLOW PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 2182119 | Fan Scroll (Includes #13) |
| 2 | 2155590 | Retainer, Fan Motor |
| 3 | 2161231 | Air Scoop |
| 5 | 2176071 | Air Duct Freezer (Includes #16) |
| 6 | 2149544 | Diffuser Air Duct |
| 7 | 2154976 | Fan Motor |
| 8 | 2169142 | Fan Blade |
| 10 | 2176759 | Grommet, Fan (2) |
| 11 | 2182146 | Duct, Icemaker |
| 12 | 2189564 | Harness, Fan, Evaporator, And Heater |
| 13 | 2155788 | Gasket, Fan Scroll |
| 14 | 2172840 | Strap |
| 16 | 2155783 | Gasket |
| 17 | 2155611 | Cover, Evaporator |
| 18 | 489355 | Screw |
| 21 | 489478 | Screw |
| 22 | 2161484 | Support, R.S. |
| 23 | 2155766 | Support, L.S. |

# CONTROL PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 2161459 | Control Box |
| 2 | 2182151 | Tube Barrier, Thermostat (RC) |
| 3 | 489214 | Screw (3) |
| 4 | 2149705 | Light Switch |
| 5 | 2183738 | Thermostat (FC) |
| 6 | 2162057 | Defrost Timer |
| 7 | 489398 | Screw (2) |
| 8 | 2169193 | Shroud, Light |
| 9 | 2183739 | Thermostat (R.C.) |
| 10 | 2172940 | Window |
| 11 | 2172906 | Grommet, Light Bar |
| 12 | 2161466 | Slide, Thermostat |
| 13 | 489084 | Screw (2) |
| 14 | 2179920 | Light Bar (RC) |
| 15 | 486632 | Washer |
| 16 | 489290 | Screw (2) |
| 17 | 2162085 | Light Socket |
| 18 | 2172931 | Heat Shield |
| 19 | 851682 | Light Bulb |
| 20 | 2183734 | Control Box Harness |
| 21 | 940014 | Hole Plug |
| 22 | 1115375 | Clip, Wiring |
| 23 | 2196001 | Tube Barrier, Thermostat (FC) |
| 24 | 2166844 | Hole Plug |
| 25 | 2175179 | Escutcheon, Control Box |
| 26 | 2179921 | Light Bar (FC) |
| 27 | 2172941 | Window |

# UNIT PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 486692 | Speed Nut |
| 2 | 1108179 | Fan, Blade |
| 3 | 2198175 | Condenser Assembly |
| 4 | 489464 | Screw |
| 5 | 940073 | Clip |
| 6 | 489099 | Screw |
| 7 | 2149293 | Heat Shield And Drain Pan |
| 9 | 2158826 | Dampner |
| 12 | 2162358 | Cover |
| 13 | 2169412 | Overload |
| 14 | 2161324 | Clip, Defrost Heater |
| 15 | 2154755 | Relay |
| 17 | 2154718 | Capacitor |
| 19 | 509812 | Screw Grommet |
| 20 | 2182057 | Unit Cover, Bottom |
| 21 | 489396 | Clip |
| 22 | 2164518 | Evaporator |
| 24 | 2198746 | Motor, Fan |
| 25 | 1105523 | Tray, Evaporator |
| 26 | 2195108 | Unit Harness |
| 27 | 2164409 | Drier |
| 28 | 2183423 | Compressor (Includes Items 12, 13, 15, 17, 27 & 38) (Also Order |
| | 876765 | Tube Kit) |
| 30 | 2160498 | Unit Mounting Frame |
| 32 | 2181929 | Bracket, Fan Motor |
| 33 | 2175046 | Heater, Defrost |
| 34 | 2161330 | Clip |
| 35 | 2176066 | Bi-Metal, Defrost |
| 37 | 489373 | Screw |
| 38 | 2172890 | Wire Assembly |
| 39 | 1100826 | Grommet (4) |
| 40 | 489340 | Screw |
| 41 | 2155301 | Air Baffle |
| 42 | 2155547 | Clip, Heat |
| 48 | 2149717 | Unit Mounting Rail |
| 49 | 488624 | Screw |
| 50 | 1105612 | Guard, Fan |
| 51 | 2161302 | Sleeve |
| 52 | 2172840 | Wire Tie |
| 53 | 489427 | Screw |
| 54 | 850145 | Wire Connector |
| 55 | 489478 | Screw |
| 59 | 2155658 | Clip, Wire & Tube |
| 61 | 488687 | Screw |
| 62 | 934011 | Clip, Tube (3) |
| 63 | 2150347 | Union |

Following Parts Not Illustrated and Optional Parts Not Included

| | |
|---|---|
| 978025 | Valve, Access (1/4") |
| 978026 | Valve, Access (5/16") |
| 978027 | Valve, Access (3/8") |
| 978028 | Valve, Access (1/2") |
| 978029 | Valve, Access (5/8") |
| 978030 | Valve, Access (3/4") |
| 876764 | Valve, Access (3/16") |

REFRIGERANT CHARGE 5.5 oz. (R-134A)

# ICEMAKER PARTS

For Model: 3XART721F00
(Black)



| | | |
|---|---|---|
| 1 | 489084 | Screw |
| 2 | 2196035 | Fitting, Water Tube |
| 5 | 628379 | Clip, Fuse |
| 6 | 489115 | Clip |
| 7 | 2181943 | Tube, Water |
| 8 | 1106508 | Seal, Gasket |
| 9 | 489478 | Screw |
| 10 | 2175056 | Valve, Solenoid |
| 11 | 627018 | Nut, Compression |
| 12 | 1129722 | Washer (2) |
| 14 | 628337 | Washer |
| 15 | 627861 | Tube, Inlet Valve |
| 16 | 510716 | Clamp, Tube |
| 17 | 537588 | Nut, Valve |
| 18 | 2174183 | Cover |
| 19 | 488649 | Screw |
| 20 | 628282 | Mold & Heater Assembly (Also Order) |
| | 542638 | Silicone Grease |
| 21 | 836074 | Dampner |
| 22 | 628356 | Cup-Water Fill |
| 23 | 627843 | Ejector |
| 24 | 2182124 | Ice Striper |
| 25 | 2195914 | Support |
| 26 | 627796 | Retainer, Thermostat |
| 27 | 627985 | Thermostat (Also Order) |
| | 542369 | Cement Alumilastic |
| 28 | 489322 | Screw |
| 30 | 489276 | Screw |
| 31 | 2171593 | Shut Off Arm |
| 32 | 628281 | Harness, Wiring |
| 33 | 628320 | Bracket |
| 34 | 1129682 | European Water Connection Tube |
| 35 | 628377 | Module Assembly (Includes Items 37 & 38) |
| 36 | 489486 | Screw |
| 37 | 628303 | Motor |
| 38 | 489136 | Screw |
| 39 | 488208 | Screw |
| 40 | 1129179 | Nut, Compression |
| 41 | 2182414 | Heat Shield |

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch-Up Material

| | |
|---|---|
| 350942 | *Primer, White (13 Oz. Spray Can) |
| 350939 | *Enamel, Black (13 Oz. Spray Can) |
| 350930 | *Enamel, White (13 Oz. Spray Can) |
| 350956 | *Enamel, Almond (13 Oz. Spray Can) |
| 72017 | Brush Touch-Up Kit (White) |
| 72107 | Brush Touch-Up Kit (Almond) |
| 72032 | Brush Touch-up kit (Black) |

*CAUTION: The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

| | |
|---|---|
| 212643 | Sealer, Gum (4 Feet) |
| 479502 | Tape, Vinyl (3/4 x 108") |

| | |
|---|---|
| 876370 | Kit, Insulation (2 Pcs. x 3" x 24" X 48") |
| 876305 | Kit, Insulation (14 Pcs. x 3" x 24" x 48") |
| 978941 | Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8) |
| 876029 | Kit, Foam Slab (30" x 32-1/2" x 1-1/2") |
| 505587 | Sealer, Mastic (1 Qt.) |
| 503695 | Cork, Sealer (1/4 Pound) |
| 511873 | Touch-Up, White Porcelain (2 Oz.) |
| 542638 | Grease, Silicone (1/2 Oz.) |
| 542639 | Cement, Alumilastic (1-1/4 Oz.) |
| 606755 | Bag, Insulation (36-5/8" x 46") |
| 799833 | Kit, Evaporator Repair (Aluminum Epoxy) |
| 833938 | Kit, Terminal Connector |
| 2182098 | Ice Container Assembly |
| 2169939 | Ice Crusher Mechanism Assembly |

Refinishing Material

| | |
|---|---|
| 799340 | Enamel, Black (1 Qt. Uncut) |
| 799344 | Enamel, White (1 Qt. Uncut) |
| 978883 | Enamel, Almond (1 Qt. Uncut) |

LITERATURE PARTS

| | |
|---|---|
| LIT2197732 | Use & Care Guide |
| LIT2187045 | Energy Label |
| LIT628371 | Modular Icemaker Service Sheet |
| LIT2198355 | Wiring Diagram |

TORX SCREW WRENCH

| | |
|---|---|
| 1117510 | Torx Key |